



WORK FOR THE BEST IMAGE

The G&G brand owner, Ninestar Image Tech Limited is a
wholly owned subsidiary of Ninestar Corporation
Stock Code: 002180



Ninestar Image Tech Limited

Address: No.3883, Zhuhai Avenue, Xiangzhou District, Zhuhai Guangdong, P.R. China 519060

TONER CARTRIDGES


**Quality Proved by Worldwide
Millions of Users**

Premium toner and
components Proprietary Patented technology
Equivalent to OEM quality stable
printing performance.

www.ggimage.com Info@ggimage.com



KEY PATENT TECHNOLOGY FOOTPRINT-LASER



Blue Drive™ Technology



Ninestar's dongle gear products featured **Blue Drive™** Technology care your printing experience.



INNOVATION DRIVEN FUTURE

Printing Solution for New HP Jet Intelligence Series Products

More Colorful | More Stable | Much Safer

Welcome to Ninestar florid colorful world

For use with: Brother

Niestar Model NO.	PageYield		OEM Model	Color	For use in
	OEM	Ninestar			
NT-PB210BK	2200	2200	TN-210BK/TN-230BK/TN-290BK/TN-240BK	●	Brother HL-3040CN/3070CW/3045CN/3075CW; MFC-9010CN/9120CW/9320CW/9125CN/9325CW
NT-PB210C	1400	1400	TN-210C/TN-230C/TN-290C/TN-240C	●	
NT-PB210M	1400	1400	TN-210M/TN-230M/TN-290M/TN-240M	●	
NT-PB210Y	1400	1400	TN-210Y/TN-230Y/TN-290Y/TN-240Y	●	Brother HL-3140CW/3150CDW/3170CDW; MFC9130CW/9140CDN/9330CDW/9340CDW
NT-PB221BK	2500	2500	TN-221BK/TN-241BK/TN-291BK/TN-251BK/TN-261BK	●	
NT-PB221C	1400	1400	TN-221C/TN-241C/TN-291C/TN-251C/TN-265C/TN-261C	●	
NT-PB221M	1400	1400	TN-221M/TN-241M/TN-291M/TN-251M/TN-265M/TN-261M	●	
NT-PB221Y	1400	1400	TN-221Y/TN-241Y/TN-291Y/TN-251Y/TN-265Y/TN-261Y	●	
NT-PB225C	2200	2200	TN-225C/TN-245C/TN-265C/TN-295C/TN-255C	●	
NT-PB225M	2200	2200	TN-225M/TN-245M/TN-265M/TN-295M/TN-255M	●	
NT-PB225Y	2200	2200	TN-225Y/TN-245Y/TN-265Y/TN-295Y/TN-255Y	●	
NT-PB242BK	2500	2500	TN-242BK	●	
NT-PB246M	2200	2200	TN-246M	●	Brother HL-3152CDW/3142CDW/3172CDW; DCP-9022CDW;MFC-9332CDW/9342CDW
NT-PB246Y	2200	2200	TN-246Y	●	
NT-PB242C	1400	1400	TN-242C	●	
NT-PB242M	1400	1400	TN-242M	●	
NT-PB242Y	1400	1400	TN-242Y	●	
NT-PB246C	2200	2200	TN-246C	●	Brother HL-1110/1112A/1210/1212;DCP-1510/1512/ 1610/1612;MFC-1810/1815/1910
NT-PB1000	1000	1000	TN-1050/TN-1075/TN-1060/TN1070	●	
NT-PB1000L	1000	2000		●	
NT-PB420	1200	1200	TN-420/TN-2210/TN-2235/TN-2230/TN-2260	●	Brother HL-2130/2132/2240/2240D/2250DN/2270DW/ 2220/2270DW/2275DW;DCP-7055/7060/7065DN/7060D; MFC-7360/7460DN/7860D/7240/7360N/7860DW; IntelliFax-2840/2940
NT-PB450	2600	2600	TN-450/TN-2220/TN-2275/TN-27J/TN-2250/TN-2280	●	
NT-PB450L	2600	5000		●	
NT-PB630	1200	1200	TN-630/TN-2310/TN-2335/TN-2340/TN-2330/TN-2305	●	Brother DCP-L2520DW/L2540DW/L2500D/L2540DN; HL-L2320D/L2340DW/L2360DW/L2380DW/L2300D/ L2360DN/L2365DW;MFC-L2700DW/L2720DW/L2740DW
NT-PB660	2600	2600	TN-660/TN-2320/TN-2375/TN-2370/TN-28J/TN-2350/ TN-2355	●	
NT-PB660L	2600	5200	TN-2355	●	
NT-PB720	3000	3000	TN-720/TN-3330/TN-53J/TN-3310/TN-3320	●	Brother HL-5440D/5450DN/5450DNT/5470DW/5470DWT/ 6180DW/6180DWT/5452DN/5472DW/5472DWT/6182DW/ 6182DWT;MFC-8710DW/8910DW/8950DW/8950DWT/ 8510DN/8810DW/8512DN/8712DW/8912DW/8952DW/ 8520DN;DCP-8250DN/8110DN/8150DN/8155DN/ 8152DN/8157DN
NT-PB750	8000	8000	TN-750/TN-3380/TN-56J/TN-3340/TN-3350	●	
NT-PB780	12000	12000	TN-780/TN-3392/TN-3390/TN-3360/TN-3370	●	Brother HL-6180DW/6180DWT/6182DW/6182DWT; MFC-8950DW/8950DWT/8912DW/8952DW
NT-PB2005	1500	1500	TN-2005/TN-2085/TN-2035	●	
NT-PB330	1500	1500	TN-330/TN-2110/TN-2135/TN-2130	●	Brother HL-2140/2170W/2150N;DCP-7030/7040; MFC-7440N/7840W/7340/7345N
NT-PB350	2500	2500	TN-350/TN-2000/TN-2075/TN-25J/TN-2025/TN-2050	●	
NT-PB350L	2500	5000		●	Brother HL 2040/2045/2070/2460/2075N/2070N;DCP7020/ 7010/7025;MFC-7220/7225/7420/7820/7220/7225N/7420/ 7820N;intellifax-2820/2920/2910
NT-PB350X	2500	4000		●	
NT-PB360	2600	2600	TN-360/TN-2120/TN-2175/TN-26J/TN-2150	●	Brother HL-2140/2170W/2150N;DCP-7030/7040; MFC-7440N/7840W/7340/7345N
NT-PB360L	2600	5200		●	
NT-PB360X	2600	4500		●	Brother HL-5240/5250DN/5250DNT/5280DW;DCP-8060/ 8065DN;MFC-8460N/8660DN/8670DN/8860DN/8870DW
NT-PB550	3500	3500	TN-550/TN-3130/TN-35J/TN-3145	●	
NT-PB580U	7000	8000	TN-550/TN-580/TN-620/TN-650/TN-3130/TN-3170/ TN-3230/TN-3280/TN-35J/TN-37J/TN-43J/TN-48J/ TN-3145/TN-3185/TN-3250/TN-3290	●	Brother HL-5240/5250DN/5250DNT/5280DW/5270DN/ 5340D/5350DN/5370DW/5380DN/5370DWT;DCP-8060/ 8065DN/8085DN/8080DN/8380DN/8480DN/8890DW/ 8880DN;MFC-8460N/8660DN/8670DN/8860DN/8870DW/ 8680DN/8690DW/8370DN
NT-PB580XU	7000	12000		●	
NT-PB620	3000	3000	TN-620/TN-3230/TN-43J/TN-3250	●	Brother HL 5340D/5350DN/5370DW/5380DN/5370DWT; DCP-8085DN/8080DN/8380DN/8480DN/8890DW/8880DN; MFC-8680DN/8690DW/8370DN
NT-PB650	8000	8000	TN-650/TN-3280/TN-48J/TN-3290	●	
NT-PB3430	3000	3000	TN-3520/TN-3492S	●	Brother HL-L5000D/L5100DN/L5200DW/L5200DWT/ L6200DW/L6200DWT/L6250DW/L6300DW/L6400DW/ L6400DWT;DCP-L5500DN/L5600DN/L5650DN; MFC-L5700DW/L5800DW/L5850DW/L5900DW/L6700DW/ L6750DW/L6800DW/L6900DW

For use with: Brother

Niestar Model NO.	PageYield		OEM Model	Color	For use in
	OEM	Ninestar			
NT-PB3480	8000	8000	TN-3520/TN-3492S	●	Brother HL-L5000D/L5100DN/L5200DW/L5200DWT/ L6200DW/L6200DWT/L6250DW/L6300DW/L6400DW/ L6400DWT/L5102DW/L5202DW/L6202DW/L6402DW; DCP-L5500DN/L5600DN/L5650DN/L5502DN/L5602DN/ L5652DN;MFC-L5700DW/L5800DW/L5850DW/L5900DW/ L6700DW/L6750DW/L6800DW/L6900DW/L5702DW/ L5802DW/L5902DW/L6702DW/L6902DW
NT-PB3512	12000	12000		●	Brother HL-L6200DWT/L6250DW/L6400DWT/L6200DW/ L6300DW/L6400DW/L5102DW/L5202DW/L6202DW/ L6402DW;MFC-L6700DW/L6750DW/L6800DW/L6900DW; DCP-L5502DN/L5602DN/L5652DN;MFC-L5702DW/ L5802DW/L5902DW/L6702DW/L6902DW
NT-PB3520	20000	20000		●	Brother HL-L6400DW/HL-L6400DWT;MFC-L6900DW
NT-PB820	3000	3000	TN-820/TN-3449/TN-3449	●	Brother HL-L5000D/L5100DN/HL5200DW/L5200DWT/ L6200DW/L6200DWT/L6250DW/L6300DW/L6400DW/ L6400DWT;DCP-L5500DN/L5600DN/L5650DN; MFC-L5700DW/5800DW/L5850DW/L5900DW/L6700DW/ L6750DW/L6800DW/L6900DW
NT-PB850	8000	8000	TN-850/TN-3479/TN-3440	●	Brother HL-L6200DWT/L6250DW/L6400DWT/L6200DW/ L6300DW/L6400DW;MFC-L6700DW/L6750DW/L6800DW/ L6900DW
NT-PB880	12000	12000	TN-880/TN-3499/TN-3470	●	
NT-PB890	20000	20000	TN-890/TN-3490	●	Brother HL-L6400DW/HL-L6400DWT;MFC-L6900DW

For use with: HP

Niestar Model NO.	PageYield		OEM Model	Color	For use in
	OEM	Ninestar			
NT-PH2612	2000	2000	Q2612A/CRG303/CRG703	●	HP LaserJet 1010/1012/1015/1018/1020/1022/1022n/ 1022nw/3015/3020/3030/3050/3052/3055/M1005 MFP/ M1300 MFP/1319f MFP;Canon LBP 2900/3000
NT-PH2612U	2000	2000	Q2612A/CRG303/CRG104/CRG703/FX10/CRG304	●	HP LaserJet 1010/1012/1015/1018/1020/1022/1022n/ 1022nw/3015/3020/3030/3050/3052/3055/M1005 MFP/ M1300 MFP/1319f MFP;Canon LBP 2900/3000; Canon FaxPhone L120/L90;FAX L100/L120; i-SENSYS 4140/MF4380dn/MF4010/MF4660pl/MF4100/ 4690pl/MF4110/MF4120/MF4140/MF4150/MF4270/ MF4320d/MF4330d/MF4340d/4050/MF4350d/4120/ MF4370dn;Satera D450/MF4120/MF4130/MF4150/ MF4330d/MF4350d/MF4370dn/4380dn/MF6570; imageCLASS D420/D480/MF4150/MF4270/MF4350/ MF4350d//MF4370/MF4370dn/MF4380dn/MF4690
NT-PH2612X	2500	2500	Q2612A/CRG303/CRG703	●	HP LaserJet 1010/1012/1015/1018/1020/1022/1022n/ 1022nw/3015/3020/3030/3050/3052/3055/M1005 MFP/ M1300 MFP/1319f MFP;Canon LaserShot LBP2900/3000
NT-PH2612	2000	2000	Q2612A/CRG303/CRG703	●	HP LaserJet 1010/1012/1015/1018/1020/1022/1022n/ 1022nw/3015/3020/3030/3050/3052/3055/M1005 MFP/ M1300 MFP/1319f MFP;Canon LBP 2900/3000
NT-PH2612X	2000	2500	Q2612A/CRG303/CRG703	●	HP LaserJet 1010/1012/1015/1018/1020/1022/1022n/ 1022nw/3015/3020/3030/3050/3052/3055/M1005 MFP/ M1300 MFP/1319f MFP;Canon LaserShot LBP2900/3000
NT-PH278C	2100	2100	CE278A/CRG126/CRG726/CRG326	●	HP LaserJet Pro P1560/P1566/P1606/P1606dn/ M1536dnf MFP;Canon LASERSHOT LBP6200/6200d; i-SENSYS LBP6200d



For use with: HP

Niestar Model NO.	PageYield		OEM Model	Color	For use in
	OEM	Ninestar			
NT-PH278CU	2100	2100	CE278A/CRG126/CRG128/CRG726/CRG728/CRG326/CRG328	●	HP LaserJet Pro P1560/P1566/P1606dn/M1536dnf MFP; Canon imageCLASS MF4410/MF4412/MF4420n/D520/D530/D550/MF4450/MF4452/MF4550d/MF4570dn/MF4570dw/MF4770n/MF4880dw/MF4890dw; i-SENSYS MF4410/MF4430/MF4450/MF4550d/MF4570dn/MF4580dn/FAX-L150/FAX-L170/LBP6200d; FAXPHONE L100/L190
NT-PH278LC	2100	3000	CE278A/CRG126/CRG726/CRG326	●	HP LaserJet ProP1566/P1606DN/P1560/P1600; CanoniMF4410/MF4430/MF4450/MF4550D/MF4570dn/MF4580dn/4420n
NT-PH283C	1500	1500	CF283A	●	HP Laserjet Pro M125/125FW/125A/M127/M127FW/FN/M201/M225MFP
NT-PH283XC	2200	2200	CF283X	●	HP LaserJet Pro MFP M225DN/M225DW/M201DW
NT-PH283XCU	2200	2200	CF283X/CRG137/HP283A/CRG737	●	HP Laserjet Pro M125/125FM/125A/M127/M127FW/FN/M201/M225MFP/MFP M225DN/M225DW/M201DW; Canon Image Class MF229dw/MF226dn/MF216n/MF224dw/MF222dw/MF217w/MF211/MF212w/MF227dw
NT-PH283ALC	2500	2500	CF283A	●	HP Laserjet Pro M125/125FW/125A/M127/M127FW/FN/M201/M225MFP
NT-PH285C	1600	1600	CE285A/CRG125/CRG725/CRG325	●	HP LaserJet Pro P1102/P1102w/1214nfh/M1132/M1212nf MFP/M1217nfw MFP; HotSpot LaserJet Pro M1218nfs; Canon imageCLASS MF3010 MFP; i-SENSYS LBP-6000/6000B/6020/6020B/MF-3010
NT-PH285LC	1600	3000	CE285A/CRG125/CRG725/CRG325	●	HP LaserJet ProP1100/M1130/M1210MFP/P1102W/M1536DNF; CanonLBP-6000/6018
NT-PH388C	1500	1500	CC388A	●	HP LaserJet P1007/P1008/P1106/P1108/M1136/M1213nf/M1216nfh
NT-PH435CUJJ	2000	2000	CB435A/CB436A/CE285A/CRG125/CRG712/CRG713/CRG725/CRG312/CRG313/CRG325	●	HP Laserjet P1005/P1006/P1505/P1505N/M1120/M1120 MFP/M1522/1522F/M1522N/M1522NF/M1550/P1102/P1102W/PRO M1130/M1212NF
NT-PH435C	1500	1500	CB435A/CRG712/CRG312	●	HP LaserJet P1005/P1006; Canon i-SENSYS LBP-3010/3100; LASERSHOT LBP-3050/3150/3018/3108
NT-PH435CU	2000	2000	CB435A/CB436A/CE285A/CRG125/CRG712/CRG713/CRG725/CaR125/CRG312/CRG313/CRG325	●	HP Laserjet P1005/P1006/1505/P1505N/M1120/M1120 MFP/M1522/1522F/M1522N/M1522NF/M1550/P1102/P1102W/PRO M1130/M1212NF
NT-PH435CUU	2000	2000	CB435A/CB436A/CE285A/CE278A/CRG128/CRG728/CRG328	●	HP Laserjet P1005/P1006/P1505/P1505N/M1120/M1120 MFP/M1522/1522F/M1522N/M1522NF/M1550/P1102/P1102W/PRO M1130/M1212NF/M1536 MFP/P1560/P1566/P1606; LaserJet Pro P1102/P1102w/1214nfh/M1132/M1212nf MFP/M1217nfw MFP; Canon LBP6200D
NT-PH435LC	1500	3000	CB435A/CRG712/CRG312	●	HP Laserjet P1005/P1006; Canon LBP-3050/3100/3150/3010/3018/3108
NT-PH436C	2000	2000	CB436A/CRG713/CRG313	●	HP LaserJet P1505/1505n/M1120 MFP/M1120n MFP/M1522n MFP/M1522nf MFP; Canon i-SENSYS LBP-3250
NT-PH436LC	2000	3000	CB436A/CRG713/CRG313	●	HP LaserJet P1505/P1505n/M1120/M1120MFP/M1522/1522F/M1522N/M1522nf/M1550; CanonLBP-3250
NT-PH279C	1000	1000	CF279A	●	HP Laserjet Pro M12a/M12w; MFP M26a/M26w/M26nw HP LaserJet Pro M12a/M12w; MFP M26a/M26w/M26nw HP LaserJet Pro 200 color Printer M251n/nw/ MFP M276n/nw; Canon i-SENSYS LBP-7100CN/110CW; SateraLBP7100C
NT-PH279LC	1000	2500	CF279A	●	
ST-PH210FBK	1600	1600	CF210A/CRG131BK/CRG731BK/CRG331BK	●	
ST-PH210XFBK	2400	2400	CF210X/CRG131IBK/CRG731HBK/CRG331IBK/CF210XBK	●	
ST-PH211FC	1800	1800	CF211A/CRG131C/CRG731C/CRG331C	●	
ST-PH212FY	1800	1800	CF212A/CRG131Y/CRG731Y/CRG331Y	●	
ST-PH213FM	1800	1800	CF213A/CRG131M/CRG731M/CRG331M/CRG731Y	●	
ST-PH210FBK	1600	1600	CF210A/CRG131BK/CRG731BK/CRG331BK	●	
ST-PH210XFBK	2400	2400	CF210X/CRG131IBK/CRG731HBK/CRG331IBK/CF210XBK	●	
ST-PH211FC	1800	1800	CF211A/CRG131C/CRG731C/CRG331C	●	
ST-PH212FY	1800	1800	CF212A/CRG131Y/CRG731Y/CRG331Y	●	
ST-PH213FM	1800	1800	CF213A/CRG131M/CRG731M/CRG331M/CRG731Y	●	

For use with: HP

Niestar Model NO.	PageYield		OEM Model	Color	For use in
	OEM	Ninestar			
ST-PH540FBK	2200	2200	CB540A/CRG116BK/CRG716BK/CRG316BK	●	HP Color LaserJet CP1215/CP1217/CP1510/CP1514/CP1515n/CP1518ni/CM1312 MFP/CM1312n MFP/CM1312nfi MFP; Canon i-SENSYS LBP5050/LBP5050n/MF8030Cn/MF8040CN/MF8050Cn/MF8080Cw; imageCLASS MF8050cn/MF8080Cw; Satera MF8050Cn/MF8030Cn(Jp)
ST-PH541FC	1400	1400	CB541A/CRG116C/CRG716C/CRG316C	●	
ST-PH542FY	1400	1400	CB542A/CRG116Y/CRG716Y/CRG316Y	●	
ST-PH543FM	1400	1400	CB543A/CRG116M/CRG716M/CRG316M	●	
ST-PH540FBK	2200	2200	CB543A/CRG116M/CRG716M/CRG316M	●	
ST-PH541FC	1400	1400	CB543A/CRG116M/CRG716M/CRG316M	●	
ST-PH542FY	1400	1400	CB543A/CRG116M/CRG716M/CRG316M	●	HP Color LaserJet Enterprise MFP M680DN/M680F/M680Z; LaserJet Pro CP1525n/CP1525nw/CM1415fn MFP/CM1415fnw MFP
ST-PH543FM	1400	1400	CB543A/CRG116M/CRG716M/CRG316M	●	
ST-PH320FBK	2000	2000	CE320A	●	
ST-PH321FC	1300	1300	CE321A	●	
ST-PH322FY	1300	1300	CE322A	●	HP Color LaserJet Enterprise MFP M680DN/M680F/M680Z; LaserJet Pro CP1525n/CP1525nw/CM1415fn MFP/CM1415fnw MFP
ST-PH323FM	1300	1300	CE323A	●	
ST-PH320FBK	2000	2000	CE320A	●	
ST-PH321FC	1300	1300	CE321A	●	
ST-PH322FY	1300	1300	CE322A	●	HP Color LaserJet Enterprise MFP M680DN/M680F/M680Z; LaserJet Pro CP1525n/CP1525nw/CM1415fn MFP/CM1415fnw MFP
ST-PH323FM	1300	1300	CE323A	●	
ST-PH305FBK	2200	2200	CE410A	●	
ST-PH305XFBK	4000	4000	CE410X	●	
ST-PH305FC	2600	2600	CE411A	●	HP LaserJet Pro 300 color M351a/MFP M375nw; LaserJet Pro 400 color Printer M451nw/M451dn/M451dw/MFP M475dn/MFP M475dw
ST-PH305FY	2600	2600	CE412A	●	
ST-PH305FM	2600	2600	CE413A	●	
ST-PH380QFBK	2400	2400	CF380A	●	
ST-PH380XQFBK	4400	4400	CF380X	●	HP Color LaserJet Pro M476dn MFP/M476dw MFP
ST-PH381QFC	2700	2700	CF381A	●	
ST-PH382QFY	2700	2700	CF382A	●	
ST-PH383QFM	2700	2700	CF383A	●	
ST-PH530FBK	3500	3500	CC530A/CRG118BK/CRG718BK/CRG318BK	●	HP Color LaserJet CP2020/CP2025/CP2025n/CP2025dn/CM2320 MFP/CM2320n MFP/CM2320nf MFP/CM2320fxi MFP; Canon imageCLASS Mf8350cdn/MF8360Cdw; i-SENSYS LBP-7200Cdn/7210CDN/7660Cdn/7680Cx/MF-8330Cdn/8340cdn/8350Cdn/8360cdn/8380cdw; Satera MF8350Cdn/MF8330Cdn(JP); LBP-7200c/7200cn/7600c(JP)
ST-PH531FC	2800	2800	CC531A/CRG118C/CRG718C/CRG318C	●	
ST-PH532FY	2800	2800	CC532A/CRG118Y/CRG718Y/CRG318Y	●	
ST-PH533FM	2800	2800	CC533A/CRG118M/CRG718M/CRG318M	●	
ST-PH250FBK	5000	5000	CE250	●	HP Color LaserJet CP3525n/CP3525dn/CP3525X/CP3520/CM3530fs MFP/CM3530 MFP
ST-PH250XFBK	10500	10500	CE250X	●	
ST-PH251FC	7000	7000	CE251	●	
ST-PH252FY	7000	7000	CE252	●	
ST-PH253FM	7000	7000	CE253	●	HP Color LaserJet Enterprise CP4025n/CP4025dn/CP4525n/CP4525dn/CP4525xh
ST-PH260FBK	8500	8500	CE260A	●	
ST-PH260XFBK	17000	17000	CE260X	●	
ST-PH261FC	11000	11000	CE261A	●	
ST-PH262FY	11000	11000	CE262A	●	HP CP5525n/CP5525dn/CP5525xh
ST-PH263FM	11000	11000	CE263A	●	
ST-PH270FBK	13500	13500	CE270A	●	
ST-PH271FC	15000	15000	CE271A	●	
ST-PH272FY	15000	15000	CE272A	●	HP laserJet Enterprise 700 color MFP M775dn/M775f/M775z
ST-PH273FM	15000	15000	CE273A	●	
ST-PH340FBK	13500	13500	CE340A	●	
ST-PH341FC	16000	16000	CE341A	●	
ST-PH342FY	16000	16000	CE342A	●	HP Color laserjet CP5225/CP5225N/CP5225DN
ST-PH343FM	16000	16000	CE343A	●	
ST-PH740FBK	7000	7000	CE740A	●	
ST-PH741FC	7300	7300	CE741A	●	
ST-PH742FY	7300	7300	CE742A	●	
ST-PH743FM	7300	7300	CE743A	●	



For use with: HP

Niestar Model NO.	PageYield		OEM Model	Color	For use in
	OEM	Ninestar			
NT-PH507BK	5500	5500	CE400A	●	HP LaserJet Enterprise 500 color Printer M551n/M551dn/ M551xh/MFP M575dn/M575f/flow MFP M575c/ MFP M570dn/M570dw
NT-PH507XBK	11000	11000	CE400X	●	
NT-PH507C	6000	6000	CE401A	●	
NT-PH507Y	6000	6000	CE402A	●	
NT-PH507M	6000	6000	CE403A	●	
NT-PH255C	6000	6000	CE255A/CRG324/CRG724/CRG524	●	HP LaserJet Enterprise MFP M525c/MFP M525f/ MFP M525dn/P3015n/P3015d/P3015dn/P3015x/Flow M525c; LaserJet Pro M521dn MFP/M521dw MFP;Canon i-SENSYS LBP-6750dn/6780X;imageCLASS MF515DW
NT-PH255XC	12500	12500	CE255X/CRG324II/CRG724H/CRG524II/CRG324H	●	
NT-PH255XLC	12500	15000	CE255X/CRG324II/CRG724H/CRG524II/CRG324H	●	
NT-PH4096	5000	5000	C4096A/EP32	●	HP LaserJet 2100/2100tn/2100se/2100m/2100xi/2200/ 2200dtn/2200dse/2200d/2200dn/2200dt
NT-PH2610	6000	6000	Q2610A	●	HP LaserJet 2300/2300d/2300L/2300dn/2300dtn
NT-PH2610C	6000	6000	Q2610A	●	
NT-PH280C	2700	2700	CF280A	●	
NT-PH280CU	2700	2700	CF280A	●	HP LaserJet Pro 400 M401/M401a/M401n/M401d/M401dn/ M401dne/M401dw/MFP/M425/MFP/M425dn/MFP/M425dw
NT-PH280XC	6900	6900	CF280X	●	HP LaserJet P2035/P2035n/P2055d/P2055dn/P2055x; LaserJet Pro 400 M401/M401a/M401n/M401d/M401dn/ M401dne/M401dw/MFP M425/MFP M425dn/MFP M425dw; Canon i-SENSYS LBP6300dn/6310dn/6650dn/6670dn/ 6680x/MF5840dn/MF5880dn/MF5940dn/MF5980dw; LBP6300/6300dn/6600/6650/6650dn/MF5870dn/MF5980dw;
NT-PH280XCU	6900	6900	CF280X	●	HP LaserJet P2055d/P2055dn/P2055x; LaserJet Pro 400 M401/M401a/M401n/M401d/M401dn/ M401dne/M401dw/MFP M425/MFP M425dn/MFP M425dw; Canon i-SENSYS LBP6300dn/6310dn/6650dn/6670dn/ 6680x/MF5840dn/MF5880dn/MF5940dn/MF5980dw; LBP6300/6300dn/6600/6650/6650dn/MF5870dn/MF5980dw;
ST-PH281CW	10500	10500	CF281A	●	HP LaserJet Enterprise MFP M630z/M630H/M630DNHP/ M604/M605/M606
ST-PH281XCW	25000	25000	CF281X	●	HP LaserJet Enterprise Flow MFP M630z/M630H/ M630DN/M605/M606
NT-PH364CW	10000	10000	CC364A	●	HP LaserJet P4015n/P4015dn/P4015x/P4015tn/P4515n/ P4515tn/P4515x
NT-PH364LC	24000	35000	CC364X	●	HP laserjet P4015N/P4015TN/P4015X/P4515N/P4515TN/ P4515X
NT-PH364XCW	24000	24000	CC364X	●	
NT-PH281CW	10500	10500	CF281A	●	HP LaserJet Enterprise Flow MFP M630z/M630H/M630DN/ M604n/M604dn/M605n/M605dn/M605x/M606dn/M606x
NT-PC039C	11000	11000	CRG 039	●	Canon LBP351dn/352dn
NT-PC039XC	25000	25000	CRG 039H	●	
NT-PH390ALC	10000	18000	CE390A	●	HP LaserJet Enterprise 600 Printer M602n/M602dn/ M602x/M603n/M603dn/M603xh/M4555f MFP/ M4555h MFP/M4555fskm MFP
NT-PH390CW	10000	10000	CE390A	●	HP laserjet Enterprise M4555/h/f/fskm/MFP/600 M602/603
NT-PH390XCW	24000	24000	CE390X	●	
NT-PH390XLC	24000	24000	CE390X	●	HP LaserJet Enterprise 600 Printer M602n/M4555f MFP
NT-PH5945XXCU	24000	24000	Q5945A/Q1338A/Q1339A/Q5942X	●	HP LaserJet 4250/4250N/4250TN/4250DTN/4250DTNSL/ 4350/4350N/4350TN/4350DTN/4350DTNSL/4200/4200N/ 4200TN/4200DTN/4200DTNS/4200DTNSL/4300/4300N/ 4300TN/4300DTN/4300DTNS/4300DTNSL/4345 MFP/ 4345x MFP/4345xs MFP/4345xm MFP/M4345xm MFP/ M4345xs MFP
NT-PH5942XLCUW	27000	27000	Q5942X/Q1338A/Q1339A/Q5945A	●	HP LaserJet 4240N/4250/4250N/4250TN/4250DTN/ 4250DTNSL/4350/4350N/4350TN/4350DTN/4350DTNSL/ 4200/4200N/4200TN/4200DTN/4200DTNS/4200DTNSL/ 4300/4300N/4300TN/4300DTN/4300DTNS/4300DTNSL/ 4345 MFP/4345x MFP/4345xs MFP/4345xm MFP/ M4345xm MFP/M4345xs MFP
ST-PH5942CUW	10000	10000	Q5942A/Q1338A/Q1339A/Q5945A	●	HP LaserJet 4250/4250N/4250TN/4250DTN/4250DTNSL/ 4350/4350N/4350TN/4350DTN/4350DTNSL/4200/4200N/ 4200TN/4200DTN/4200DTNS/4200DTNSL/4300/4300N/ 4300TN/4300DTN/4300DTNS/4300DTNSL/4345 MFP/ 4345x MFP/4345xs MFP/4345xm MFP/M4345xm MFP/ M4345xs MFP
ST-PH5942XCUW	20000	20000	Q5942X/Q1338A/Q1339A/Q5945A	●	HP ColorLaserjet M452DN/M452DW/M452NW/ M477FND/M477FWD/M477FNW
NT-PH410XBK	6500	6500	CF410X	●	HP ColorLaserjet M452DN/M452DW/M452NW/ M477FND/M477FWD/M477FNW
NT-PH411XC	5000	5000	CF411X	●	
NT-PH412XY	5000	5000	CF412X	●	
NT-PH413XM	5000	5000	CF413X	●	

For use with: HP

Niestar Model NO.	PageYield		OEM Model	Color	For use in
	OEM	Ninestar			
NT-PH4127	6000	6000	C4127A/EP-52/C4127X	●	HP LaserJet 4000/4000n/4000t/4000tn/4000se/4050/4050t/ 4050n/4050tn/4050se/4050 USB-MAC Printer; Canon LBP-1760/1760E/52X
NT-PH4127X	10000	10000	C4127X/EP-52	●	
NT-PH505C	2300	2300	CE505A/CRG119/CRG719/CRG519/CRG319	●	HP LaserJet P2035/P2035n/P2055d/P2055dn/P2055x; Canon i-SENSYS LBP6300dn/6310dn/6650dn/6670dn/ 6680x/MF5840dn/MF5880dn/MF5940dn/MF5980dw; LBP6300/6300dn/6600/6650/6650dn/MF5870dn/MF5980dw
NT-PH505CU	2300	2300	CE505A/CF280A	●	HP LaserJet P2035/P2035n/P2055d/P2055dn/P2055x; LaserJet Pro 400 M401/M401a/M401n/M401d/M401dn/ M401dne/M401dw/MFP M425/MFP M425dn/MFP M425dw; Canon i-SENSYS LBP6300dn/6310dn/6650dn/6670dn/ 6680x/MF5840dn/MF5880dn/MF5940dn/MF5980dw; LBP6300/6300dn/6600/6650/6650dn/MF5870dn/MF5980dw;
NT-PH505LC	2300	3500	CE505A/CRG119/CRG719/CRG519/CRG319	●	HP LaserJet P2035/P2035n/P2055d/P2055dn/P2055x; Canon i-SENSYS LBP6300dn/6310dn/6650dn/6670dn/ 6680x/MF5840dn/MF5880dn/MF5940dn/MF5980dw; LBP6300/6300dn/6600/6650/6650dn/MF5870dn/MF5980dw
NT-PH505XC	6500	6500	CE505X/CRG119II/CRG719H/CRG519II/CE505A/CRG319II	●	HP LaserJet P2055d/P2055dn/P2055x; Canon i-SENSYS LBP6300dn/6310dn/6650dn/6670dn/ 6680x/MF5840dn/MF5880dn/MF5940dn/MF5980dw; LBP6300/6300dn/6600/6650/6650dn/MF5870dn/MF5980dw; Laser Printers ImageRUNNER LBP-3470/ ImageRUNNER LBP-3480/LaserCLASS 650i
NT-PH505XCU	6500	6500	CE505X/CF280X	●	HP LaserJet P2055d/P2055dn/P2055x; LaserJet Pro 400 M401/M401a/M401n/M401d/M401dn/ M401dne/M401dw/MFP M425/MFP M425dn/MFP M425dw; Canon i-SENSYS LBP6300dn/6310dn/6650dn/6670dn/ 6680x/MF5840dn/MF5880dn/MF5940dn/MF5980dw; LBP6300/6300dn/6600/6650/6650dn/MF5870dn/MF5980dw;
NT-PH505XCUII	6500	6500	CE505X/CF280X/CRG120/CRG720/CRG320	●	HP LaserJet P2055d/P2055dn/P2055x; LaserJet Pro 400 M401/M401a/M401n/M401d/M401dn/ M401dne/M401dw/MFP M425/MFP M425dn/MFP M425dw; Canon i-SENSYS LBP6300dn/6310dn/6650dn/6670dn/ 6680x/MF5840dn/MF5880dn/MF5940dn/MF5980dw; LBP6300/6300dn/6600/6650/6650dn/MF5870dn/MF5980dw;
NT-PH505LC	2300	3500	CE505A/CRG119/CRG719/CRG519/CRG319	●	HP LaserJet P2035/P2035n/P2055d/P2055dn/P2055x; Canon i-SENSYS LBP6300dn/6310dn/6650dn/6670dn/ 6680x/MF5840dn/MF5880dn/MF5940dn/MF5980dw; LBP6300/6300dn/6600/6650/6650dn/MF5870dn/MF5980dw
NT-PH505LCU	6500	10000	CE505X/CF280X	●	HP LaserJet P2055d/P2055dn/P2055x; LaserJet Pro 400 M401/M401a/M401n/M401d/M401dn/ M401dne/M401dw/MFP M425/MFP M425dn/MFP M425dw; Canon i-SENSYS LBP6300dn/6310dn/6650dn/6670dn/ 6680x/MF5840dn/MF5880dn/MF5940dn/MF5980dw; LBP6300/6300dn/6600/6650/6650dn/MF5870dn/MF5980dw;
NT-PH505XXLCU	6500	13000	CE505X/CF280X	●	HP LaserJet P2055d/P2055dn/P2055x; LaserJet Pro 400 M401/M401a/M401n/M401d/M401dn/ M401dne/M401dw/MFP M425/MFP M425dn/MFP M425dw; Canon i-SENSYS LBP6300dn/6310dn/6650dn/6670dn/ 6680x/MF5840dn/MF5880dn/MF5940dn/MF5980dw; LBP6300/6300dn/6600/6650/6650dn/MF5870dn/MF5980dw;
NT-PH505XLC	6500	8000	CE505X/CRG119II/CRG719H/CRG519II/CE505A/CRG319II	●	HP LaserJet P2055D/2055DN/2055X
NT-PH5949C	2500	2500	Q5949A/CRG308/CRG708/CRG508	●	HP LaserJet 1160/1160Le/1320/1320n/1320t/1320tn/ 1320nw/3390/3392;Canon LBP-3300/3360
NT-PH5949CU	2500/3000	3000	Q5949A/Q7553A/CRG308/CRG315/CRG708/CRG715/ CRG508/CRG515	●	HP LaserJet 1160/1160Le/1320/1320n/1320t/1320tn/ 1320nw/3390/3392/P2010/P2014/P2015/P2015n/P2015d/ P2015dn/P2015dn/P2015x/M2727nf MFP/M2727nfs MFP; Canon LBP-3300/3360/3310/3370;
NT-PH5949LC	2500	4000	Q5949A/CRG308/CRG708/CRG508	●	HP LaserJet 1160/1160LE/1320/1320N/1320TN/1320NW/ 3392/3390;CanonLBP3300
NT-PH5949XC	6000	6000	Q5949X/CRG308II/CRG708H/Q5949A/CRG508II/ CRG308/Q5949XC	●	
NT-PH5949XCU	6000/7000	7000	Q5949X/Q7553X/CRG108H/CRG708H/CRG715H/ CRG508II/CRG515II/CRG308H/CRG315H	●	HP LaserJet 1320/1320n/1320t/1320tn/1320nw/3390/3392/ P2010/P2014/P2015/P2015n/P2015d/P2015dn/P2015dn/ P2015x/M2727nf MFP/M2727nfs MFP;Canon LBP-3310/ 3370/3300/3360
NT-PH5949XLC	6000	9000	Q5949X/CRG308II/CRG708H/Q5949A/CRG508II/ CRG308/Q5949XC	●	HP LaserJet 1160/1160LE/1320/1320N/1320TN/1320NW/ 3392/3390;CanonLBP3300
NT-PH7553	3000	3000	Q7553A/CRG715/CRG315/Q5949A	●	HP LaserJet P2010/P2014/P2015/P2015n/P2015d/ P2015dn/P2015dn/P2015x/M2727nf MFP/M2727nfs MFP; Canon LBP-3310/3370
NT-PH7553X	7000	7000	Q7553X/CRG715H/CRG315H/CRG315II	●	
NT-PH7553LC	3000	4000	Q7553A/CRG715/CRG315/Q5949A	●	HP LaserJet P2015/P2015D/P2015N/M2727nf
NT-PH6511	6000	6000	Q6511A/CRG310/CRG710	●	HP LaserJet 2410/2420/2420n/2420d/2420dn/2430/2430n/ 2430t/2430tn/2430dtn;Canon imageRUNNER LBP3460; i-SENSYS LBP3460
NT-PH6511C	6000	6000	Q6511A/CRG310/CRG710	●	
NT-PH6511X	12000	12000	Q6511X/CRG310II/CRG710H/CRG310H	●	HP LaserJet 2410/2420/2420n/2420d/2420dn/2430/2430n/ 2430t/2430tn/2430dtn;Canon imageRUNNER LBP3460; i-SENSYS LBP3460
NT-PH6511XC	12000	12000	Q6511X/CRG310II/CRG710H/CRG310H	●	



For use with: HP

Niestar Model NO.	PageYield		OEM Model	Color	For use in
	OEM	Ninestar			
ST-PH9730FBK	13000	13000	C9730A	●	HP Color LaserJet 5500/5500n/5500dn/5500hdn/5500dtn /5550/5550n/5550dtn/5550hdn
ST-PH9731FC	12000	12000	C9731A	●	
ST-PH9732FY	12000	12000	C9732A	●	
ST-PH9733FM	12000	12000	C9733A	●	
ST-PH507FBK	5500	5500	CE400	●	HP LaserJet Enterprise 500 color Printer M551n/M551dn/ M551xh/MFP M575dn/M575f/flow MFP M575c/ MFP M570dn/M570dw
ST-PH507XFBK	11000	11000	CE400X	●	
ST-PH507FC	6000	6000	CE401	●	
ST-PH507FM	6000	6000	CE403	●	
ST-PH507FY	6000	6000	CE402	●	
ST-PH5942XLCFU	20000	30000	Q1338A/Q5942X/Q1339A/Q5945A	●	HP LaserJet 4200/4200N/4200TN/4200DTN/4200DTNS/ 4200DTNSL/4300/4300N/4300TN/4300DTN/4300DTNS/ 4300DTNSL/4240/4250/4250N/4250TN/4250DTN/ 4250DTNSL/4350/4350N/4350TN/4350DTN/4350DTNSL/ 4345MFP
NT-PH255XCQF	12500	12500	CE255X/CRG324II/CRG724H/CRG324H/CRG524II	●	HP LaserJet Enterprise MFP M525c/MFP M525f/ MFP M525dn/P3015n/P3015d/P3015dn/P3015x/ Flow M525c;LaserJet Pro M521dn MFP/M521dw MFP; Canon i-SENSYS LBP-6750dn/6780X; imageCLASS MF515DW
NT-PH255CF	6000	6000	CE255A/CRG324/CRG724/CRG524	●	
NT-PH280CF	2700	2700	CF280A	●	HP LaserJet Pro 400 M401/M401a/M401n/ M401d/ M401dn/M401dne/M401dw/MFP M425/MFP M425dn/ MFP M425dw
NT-PH280CQF	2700	2700	CF280A	●	
NT-PH280XCQF	6900	6900	CF280X	●	
ST-PH364XLCF	24000	38000	CC364X	●	HP LaserJet P4015n/P4015dn/P4015x/P4015tn/P4515n/ P4515tn/P4515x
NT-PH505CF	2300	2300	CE505A/CRG119/CRG719/CRG519/CRG319	●	HP LaserJet P2035/P2035n/P2055d/P2055dn/P2055x; Canon i-SENSYS LBP6300dn/6310dn/6650dn/6670dn/ 6680x/MF5840dn/MF5880dn/MF5940dn/MF5980dw; LBP6300/6300dn/6600/6650/6650dn/MF5870dn/MF5980dw
NT-PH505XCQF	6500	6500	CE505X/CRG119II/CRG719H/CRG519II/CE505A/CRG319II		
ST-PH7551XLCF	38000	38000	Q7551X	●	HP LaserJet P3005/P3005d/P3005n/P3005dn/P3005x/ M3027 MFP/M3027x MFP/M3035xs MFP
NT-PH210BK	16001400	1600	CF210A/CRG131BK/CRG731BK/CRG331BK	●	HP LaserJet Pro 200 color Printer M251n/M251nw/ MFP M276n/M276nw;Canon i-SENSYS LBP-7100CN/ LBP-7110CW;SateraLBP7100C
NT-PH210XBK	24002400	2400	CF210X/CRG131IIBK/CRG731HBK/CRG331IIBK/CF210XBK	●	
NT-PH211C	18001500	1800	CF211A/CRG131C/CRG731C/CRG331C	●	
NT-PH212Y	18001500	1800	CF212A/CRG131Y/CRG731Y/CRG331Y	●	
NT-PH213M	18001500	1800	CF213A/CRG131M/CRG731M/CRG331M/CRG731Y	●	
NT-PH540BK	2200	2200	CB540A/CRG116BK/CRG716BK/CRG316BK	●	HP Color LaserJet CP1215/CP1217/CP1510/CP1514/ CP1515n/CP1518ni/CM1312 MFP/CM1312n MFP/ CM1312nfi MFP;Canon i-SENSYS LBP5050/LBP5050n/ MF8030Cn/MF8040CN/MF8050Cn/MF8080Cw; imageCLASS MF8050cn/MF8080Cw;Satera MF8050Cn/ MF8030Cn(Jp)
NT-PH541C	1400	1400	CB541A/CRG116C/CRG716C/CRG316C	●	HP Color LaserJet CP1215/CP1217/CP1510/CP1514/ CP1515n/CP1518ni/CM1312 MFP/CM1312n MFP/ CM1312nfi MFP;Canon i-SENSYS LBP5050/LBP5050n/ MF8030Cn/MF8040CN/MF8050Cn/MF8080Cw; imageCLASS MF8050cn/MF8080Cw; Satera MF8050Cn/MF8030Cn(Jp)
NT-PH542Y	1400	1400	CB542A/CRG116Y/CRG716Y/CRG316Y	●	
NT-PH543M	1400	1400	CB543A/CRG116M/CRG716M/CRG316M	●	
NT-PH320BK	2000	2000	CE320A	●	
NT-PH321C	1300	1300	CE321A	●	HP LaserJet Pro CP1525n/CP1525nw/ CM1415fn MFP/CM1415fnw MFP
NT-PH322Y	1300	1300	CE322A	●	
NT-PH323M	1300	1300	CE323A	●	HP LaserJet Pro 300 color M351a/MFP M375nw; LaserJet Pro 400 color Printer M451nw/M451dn/ M451dw/MFP M475dn/MFP M475dw
ST-PH305BK	2200	2200	CE410A	●	
ST-PH305XBK	4000	4000	CE410X	●	
ST-PH305C	2600	2600	CE411A	●	
ST-PH305M	2600	2600	CE413A	●	
ST-PH305Y	2600	2600	CE412A	●	
NT-PH530UBK	3500	3500	CC530A/CE410X/CRG118BK/CRG718BK/CRG318BK	●	HP Color LaserJet CP2020/CP2025/CP2025n/CP2025dn/ CM2320 MFP/CM2320n MFP/CM2320nf MFP/ CM2320fxi MFP;LaserJet Pro 300 color M351a/ MFP M375nw;LaserJet Pro 400 color Printer M451nw/ M451dn/M451dw/MFP M475dn/MFP M475dw; Color LaserJet Pro M476dn MFP/M476dw MFP/ M476nw MFP;Canon imageCLASS Mf8350cdn/ MF8380Cdw;i-SENSYS LBP-7200Cdn/7210CDN/7660Cdn/ 7680Cx/MF-8330Cdn/8340cdn/8350Cdn/8360cdn/8380cdw; Satera MF8350Cdn/MF8330Cdn(JP);LBP-7200c/7200cn/ 7600c(JP);
NT-PH531UC	2800	2800	CC531A/CE411A/CRG118C/CRG718C/CRG318C	●	
NT-PH532UY	2800	2800	CC532A/CE412A/CRG118Y/CRG718Y/CRG318Y	●	
NT-PH533UM	2800	2800	CC533A/CE413A/CRG118M/CRG718M/CRG318M	●	

For use with: HP

Niestar Model NO.	PageYield		OEM Model	Color	For use in
	OEM	Ninestar			
ST-PH530BK	3500	3500	CC530A	●	HP Color LaserJet CP2020/CP2025/CP2025n/CP2025dn/ CM2320 MFP/CM2320n MFP/CM2320nf MFP/ CM2320fxi MFP;Canon imageCLASS Mf8350cdn/ MF8380Cdw;i-SENSYS LBP-7200Cdn/7210CDN/7660Cdn/ 7680Cx/MF-8330Cdn/8340cdn/8350Cdn/8360cdn/ 8380cdw;Satera MF8350Cdn/MF8330Cdn(JP); LBP-7200c/7200cn/7600c(JP)
ST-PH531C	2800	2800	CC531A	●	
ST-PH532Y	2800	2800	CC532A	●	
ST-PH533M	2800	2800	CC533A	●	
ST-PH380BK	2400	2400	CF380A	●	HP Color LaserJet Pro M476dn MFP/M476dw MFP/ M476nw MFP
ST-PH380XBK	4400	4400	CF380X	●	
ST-PH381C	2700	2700	CF381A	●	
ST-PH382Y	2700	2700	CF382A	●	
ST-PH383M	2700	2700	CF383A	●	HP Color LaserJet M252/252N/252DN/252DW/ M277n/M277DW
NT-PH201BK	1500	1500	CF400A	●	
NT-PH201C	1400	1400	CF401A	●	
NT-PH201Y	1400	1400	CF402A	●	
NT-PH201M	1400	1400	CF403A	●	HP Color LaserJet M252/252N/252DN/252DW/ M277n/M277DW
NT-PH201XBK	2800	2800	CF400X	●	
NT-PH201XC	2300	2300	CF401X	●	
NT-PH201XM	2300	2300	CF403X	●	
NT-PH201XY	2300	2300	CF402X	●	HP Color LaserJet M452DW/M452DN/M452NW/ M477FDW/477DN/M477NW
NT-PH410BK	2300	2300	HP CF410A	●	
NT-PH411C	2300	2300	HP CF411A	●	
NT-PH412Y	2300	2300	HP CF412A	●	
NT-PH413M	2300	2300	HP CF413A	●	HP Color LaserJet M452DW/M452DN/M452NW/ M477FDW/477DN/M477NW
NT-PH410XBK	6500	6500	HP CF410X	●	
NT-PH411XC	5000	5000	HP CF411X	●	
NT-PH412XY	5000	5000	HP CF412X	●	
NT-PH413XM	5000	5000	HP CF413X	●	HP LaserJet M553N/M553DN/M553X/M577C/M577Z/ M577F/M577DN
NT-PH360BK	6000	6000	HP CF360A	●	
NT-PH361C	5000	5000	HP CF361A	●	
NT-PH362Y	5000	5000	HP CF362A	●	
NT-PH363M	5000	5000	HP CF363A	●	Canon imageCLASS LBP712Cdn/LBP712Cx; Canon i-Sensys LBP710Cx/LBP712CX
NT-PC040BK	6300	6300	Cartridge 040BK	●	
NT-PC040C	5400	5400	Cartridge 040C	●	
NT-PC040Y	5400	5400	Cartridge 040Y	●	
NT-PC040M	5400	5400	Cartridge 040M	●	HP LaserJet M553N/M553DN/M553X/M577C/M577Z/ M577F/M577DN
NT-PH360XBK	12500	12500	HP CF360X	●	
NT-PH361XC	9500	9500	HP CF361X	●	
NT-PH362XY	9500	9500	HP CF362X	●	
NT-PH363XM	9500	9500	HP CF363X	●	Canon imageCLASS LBP712Cdn/LBP712Cx; Canon i-Sensys LBP710Cx/LBP712CX
NT-PC040XBK	12500	12500	Cartridge 040HBK	●	
NT-PC040XC	10000	10000	Cartridge 040HC	●	
NT-PC040XY	10000	10000	Cartridge 040HY	●	
NT-PC040XM	10000	10000	Cartridge 040HM	●	HP Color LaserJet M553N/M553DN/M553X/M577C/M577Z/ M577F/M577DN
NT-PH250BK	5000	5000	CE250A/CRG732BK/CRG332BK	●	
NT-PH250XBK	10500	10500	CE250X/CRG732HBK/CRG332IIBK	●	
NT-PH251C	7000	7000	CE251A/CRG732C/CRG332C	●	
NT-PH252Y	7000	7000	CE252A/CRG732Y/CRG332Y	●	
NT-PH253M	7000	7000	CE253A/CRG732M/CRG332M	●	HP Color LaserJet CP3525n/CP3525dn/CP3525X/ CP3520/CM3530fs MFP/CM3530 MFP
NT-PH7551	6500	6500	Q7551A	●	
NT-PH7551C	6500	6500	Q7551A	●	
NT-PH7551LC	6500	7000	Q7551A	●	
NT-PH7551X	13000	13000	Q7551X	●	HP LaserJet P3005/P3005d/P3005n/P3005dn/P3005x/ M3027 MFP/M3027x MFP/M3035xs MFP
NT-PH7551XC	13000	13000	Q7551X	●	



For use with: HP

Niestar Model NO.	PageYield		OEM Model	Color	For use in
	OEM	Ninestar			
NT-PH2613CU	2500	2500	Q2613A/C7115A/Q2624A/EP25	●	HP LaserJet 1300/1300n/1300xi/1000/1005/1200/1200n/1200se/1220/1220se/3380/3320mfp/3320nmfp/3300mfp/3330mfp/3310;Digital Printer Copier/1150; Canon LaserShot LBP-1210
NT-PH2613U	2500	2500	Q2613A/C7115A/Q2624A/EP25	●	
NT-PH2613XCU	4000	4000	Q2613X/C7115X/Q2624X/CRGEP25/EP25	●	
NT-PH2613XU	4000	4000	Q2613X/C7115X/Q2624X/CRGEP25/EP25	●	
NT-PH2624	2500	2500	Q2624A	●	
NT-PH2624X	4000	4000	Q2624X	●	HP LaserJet 1150 Printer
NT-PH7115	2500	2500	C7115A/CRGEP25	●	HP LaserJet 1000/1005/1200/1200n/1200se/1220/1220se/3380/3320mfp/3320nmfp/3300mfp/3330mfp/3310 Digital Printer Copier;Canon LaserShot LBP-1210
NT-PH7115X	3500	3500	C7115X/CRGEP25	●	
NT-PH192C	12000	12000	CZ192A	●	HP LaserJet Pro M435nw/M701/M706
NT-PH214C	10000	10000	CF214A/CRG533/CRG333	●	HP LaserJet Enterprise 700 M712N/M712DN/M712XH/M725DN/M725/M725X/M725Z
NT-PH214XC	17500	17500	CF214X/CRG533II/CRG333H	●	
NT-PH7516XC	12000	12000	Q7516A/CRG309/Q5716A/CRG709/CRG-309	●	HP LaserJet 5200/5200tn/5200dtn;Canon LBP-3500/3900/3910/3920/3930/3950/3970/3980
NT-PH8061C	6000	6000	Q8061A/C4127A	●	HP LaserJet 4100/4100n/4100tn/4100dtn/4100mfp/4101mfp/4000/4000n/4000i/4000tn/4000se/4050/4050i/4050n/4050tn/4050se/4050 USB-MAC Printer; Canon LBP-1760/1760E/52X
NT-PH8061X	10000	10000	Q8061X/C4127X	●	
NT-PH8061XC	10000	10000	Q8061X/C4127X	●	
NT-PH226C	3100	3100	HP CF226A	●	HP LaserJet Pro M402n/M402dn/M402dw/MFP M426fdw/MFP M426fdn
NT-PH226	3100	3100	HP CF226A	●	
NT-PH226XC	9000	9000	HP CF226X	●	
NT-PH226X	9000	9000	HP CF226X	●	HP LaserJet Pro M403d/M403dn/M403dw/M403n/MFP M427dw/MFP M427fdn/MFP M427fdw
NT-PH228C	3100	3100	HP CF228A	●	
NT-PH228XC	9000	9000	HP CF228X	●	
NT-PH287C	9000	9000	HP CF287A	●	HP LaserJet Enterprise MFP M527f/MFP M527dn/M506x/M506dn/M506n;LaserJet Pro M501dn; LaserJet Enterprise Flow MFP M527z
NT-PH287	9000	9000	HP CF287A	●	
NT-PH287XC	18000	18000	HP CF287X	●	
NT-PH287X	18000	18000	HP CF287X	●	

For use with: Canon

Niestar Model NO.	PageYield		OEM Model	Color	For use in
	OEM	Ninestar			
NT-PC128C	2100	2100	CRG128/CRG728/CRG328	●	Canon Image Class MF4570dn/MF4880dw/MF4890dw/D550;Canon i-SENSYS MF4410/MF4430/MF4450/MF4550d/MF4570dn/MF4580dn/MF4870dn/MF4890dw; Canon FAXPHONE L100;Canon i-SENSYS FAX-L150/L170
NT-PC303	2000	2000	CRG303/CRG703/CRG304	●	Canon LaserShot LBP2900/3000;HP Laserjet 1010/1012/1015/1018/1020/1022/3015/3020/3030/3050/3052/3055/M1005MFP/M1300MFP/M1319MFP%3F
NT-PCFX9	2000	2000	CRG104/FX-10/CRG304/FX-9	●	Canon FaxPhone L120/L90;Canon FAX L100/L120; Canon i-SENSYS 4140/MF4380dn/MF4010/MF4660pl/MF4100/4690pl/MF4110/MF4120/MF4140/MF4150/MF4270/MF4320d/MF4330d/MF4340d/4050/MF4350d/4120/MF4370dn;Canon Satera D450/MF4120/MF4130/MF4150/MF4330d/MF4350d/MF4370dn/4380dn/MF6570; Canon imageCLASS D420/D480/MF4150/MF4270/MF4350/MF4350d/MF4370/MF4370dn/MF4380dn/MF4690
NT-PC712C	1500	1500	CRG312/CRG712/CRG-312/CRG-912	●	Canon LBP-3018/3010/3050/3020/3100/3150/3018/3108
NT-PC126C	2100	2100	CRG-126/CRG-726/CRG326/CRG-326	●	Canon Image Class LBP6200d
NT-PC137C	2400	2400	CRG137/CRG737/CRG337	●	Canon Image Class MF229dw/MF226dn/MF216n/MF224dw/MF222dw/MF217w/MF211/MF212w/MF227dw

For use with: Canon

Niestar Model NO.	PageYield		OEM Model	Color	For use in
	OEM	Ninestar			
NT-PC712C	1500	1500	CRG312/CRG712/CRG-312/CRG912	●	Canon i-SENSYS LBP-3010/3100; Canon LASERSHOT LBP-3050/3150/3018/3108
ST-PC322FBK	13500	13500	CRG-322	●	Canon LBP-9650Ci/9510C/9600C/9500C/9200C/9100C
ST-PC322FC	15000	15000	CRG-322	●	
ST-PC322FM	15000	15000	CRG-322	●	
ST-PC322FY	15000	15000	CRG-322	●	Canon LBP-6600/6300
NT-PC519XCF	6400	6400	CRG119II/CRG719H/CRG-119/CRG519II/CRG319II	●	
NT-PC120CQF	5000	5000	CRG120/CRG720/CRG320	●	Canon Image Class D1100/D1120/D1150/D1170/D1180/D1320/D1350/D1370;Canon i-Sensys MF6680dn
NT-PC527CQF	15000	15000	CANON527	●	Canon LBP8630/8620/8610
NT-PC116BK	2300	2300	CRG116BK/CRG716BK/CRG316BK	●	Canon i-SENSYS LBP5050/LBP5050n/MF8030Cn/MF8040CN/MF8050Cn/MF8080Cw; Canon imageCLASS MF8050cn/MF8080Cw; Canon Satera MF8050Cn/MF8030Cn(Jp)
NT-PC116C	1500	1500	CRG116C/CRG716C/CRG316C	●	
NT-PC116M	1500	1500	CRG116M/CRG716M/CRG316M	●	
NT-PC116Y	1500	1500	CRG116Y/CRG716Y/CRG316Y	●	
NT-PC118BK	3400	3400	CRG118BK/CRG718BK/CRG318BK	●	Canon Image Class MF8350cdn/MF8380Cdw; Canon i-SENSYS LBP-7200Cdn/7210CDN/7660Cdn/7680Cx;Canon i-SENSYS MF-8330Cdn/8340cdn/8350Cdn/8360cdn/8380cdw;Canon Satera MF8350Cdn/MF8330Cdn(JP);Canon LBP-7200c/7200cn/7600c(JP)
NT-PC118C	2900	2900	CRG118C/CRG718C/CRG318C	●	
NT-PC118M	2900	2900	CRG118M/CRG718M/CRG318M	●	
NT-PC118Y	2900	2900	CRG118Y/CRG718Y/CRG318Y	●	Canon Image Class D620/D660/D661/D680/D760/D761/D780/D860/D861/D880;Canon Smartbase PC-1060/1061/1080F/1210/1210d/1230/1230d/1250/1270/1270d
NT-PCL50	5000	5000	L50/CartridgeM/CartridgeN	●	
NT-PCR41C	6400	6400	GPR-41	●	Canon Laser Printers ImageRUNNER LBP-3470/LBP-3480/Laser CLASS 650i
NT-PCEP25	2500	2500	EP-25	●	Canon LaserShot LBP1210;HP LaserJet 1000/1005/1200/1200n/1200se/1220/1220se/3300 MFP/3320 MFP/3320n MFP/3330 MFP
NT-PCEP25X	2500	4000	EP-25X	●	
NT-PCEP26	2500	2500	EP-26/EP-27	●	Canon i-SENSYS LBP-3210;Canon MF-3110/3220/5600; Canon LaserShot LBP-3200;Canon LaserBase MF-3240/5630/5650/5730/5750/5770
NT-PCS35	3500	3500	S35/CartridgeT/CartridgeW/FX8	●	Canon FaxPhone L170;Canon PC-D340/D320; Canon imageCLASS D320/D323/D340/D360/D383; Canon Fax L360/L380/L380s/L390/L390S/L398/L398s/L400/L408s
NT-PCX25	2500	2500	X25/EP27/CartridgeU	●	Canon i-SENSYS LBP-3210;Canon MF-3110/3220/5600; Canon LaserShot LBP-3200;Canon LaserBase MF-3240/5630/5650/5730/5750/5770;Canon image CLASS MF3110/MF3111/MF3220/MF3240/MF5500/MF5530/MF5550/MF5630/MF5650/MF5730/MF5750/MF5770; Canon LBP-300LDA/LBP-300LDF/LBP-300N/LBP-3200/LBP-3210
NT-PC106	5000	5000	CRG106/CRG706/CRG406/CRG306	●	Canon Image Class MF6530/ MF6540/MF6550/MF6560/MF6580/MF6590/MF6595;Canon i-SENSYS MF6530/MF6540PL/MF6550/MF6560PL/MF6580PL; Canon LaserBase MF6530/MF6540PL/MF6550PL/MF6560PL/MF6580
NT-PC120C	5000	5000	CRG120/CRG720/CRG320	●	Canon Image Class D1100/D1120/D1150/D1170/D1180/D1320/D1350/D1370;Canon i-Sensys MF6680dn
NT-PC120C	5000	5000	CRG120/CRG720/CRG320	●	

For use with: Dell

Niestar Model NO.	PageYield		OEM Model	Color	For use in
	OEM	Ninestar			
NT-PD1235BK	1500	1500	330-3012/330-3578/593-10493/592-11454	●	Dell 1230c/1235cn
NT-PD1235C	1000	1000	330-3015/330-3581/593-10496/592-11452	●	
NT-PD1235M	1000	1000	330-3014/330-3580/593-10495/592-11453	●	
NT-PD1235Y	1000	1000	330-3013/330-3579/593-10494/592-11451	●	
NT-PD1720C	3000	3000	310-8708/310-8706/593-10240/593-10238/592-10436/	●	Dell 1720/1720dn
NT-PD1720XC	6000	6000	592-10482	●	



For use with: Lexmark

Niestar Model NO.	PageYield		OEM Model	Color	For use in
	OEM	Ninestar			
NT-PFL3150	16000	16000	24B6186	●	Lexmark M3150/XM3150
NT-PK4050C	20000	20000	TNP44/TNP46	●	Konica Minolta Bizhub 4050/4750
NT-PL601C	2500	2500	60F1000/60F4000/60F2000/60F5000/60F3000/60F500E	●	Lexmark MX310dn/410de/510de/511de/511dhe/511dte/ 610de/611de/611dhe/611dte
NT-PL601XC	10000	10000	60F1H00/60F4H00/60F2H00/60F6H00/60F5H00/60F0HA0/ 60FBH00/60F3H00/60F5H0E	●	
NT-PL601XXC	20000	20000	60F1X00/60F4X00/60F2X00/60F5X00/60F0XA0/60FBX00/ 60F3X00/60F5X0E	●	Lexmark MX510de/511de/511dte/511dhe/610de/611de/ 611dte/611dhe
NT-PL521B	/	/	52D1000	●	Lexmark MS810de/810dn/810dtn/810n/811dn/811n/811dtn/ 812de/812dn/812dtn
NT-PL521C	6000	6000	52D1000/52D4000/52D2000/52D5000/52D3000/52D500E	●	
NT-PL521XC	25000	25000	52D1H00/52D0HA0/52D4H00/52D2H00/52D5H00/ 52DBH00/52D3H00/52D5H0E/52D0HA0N	●	Lexmark MS811dn/811n/811dtn/812de/812dn/812dtn
NT-PL521XXC	45000	45000	52D1X00/52D2X00/52D0XA0/52D5X00/52DBX00/ 52D3X00/52D5X0E	●	
NT-PL621C	6000	6000	62D1000/62D2000/62D5000/62D0HA0/62D3000/62D500E	●	Lexmark MX710de/710dhe/711de/711dhe/711dte/810de/ 810dte/810dxe/810dfe/810dme/810dte/810dte/810dxfe/ 810dxme/811de/811dte/811dxe/811dfe/811dme/811dte/ 811dte/811dfe/811dxme/812de/812dte/812dxe/812dfe/ 812dte/812dfe/812dme/812dte/812dxme
NT-PL621XC	25000	25000	62D1H00/62D2H00/62D5H00/62D0HA0/62DBH00/ 62D3H00/62D5H0E	●	
NT-PL621XXC	45000	45000	62D1X00/62D2X00/62D0XA0/62D5X00/62DBX00/62D5X0E	●	Lexmark MX711de/711dhe/711dte/810de/810dte/810dxe/ 810dte/810dme/810dte/810dte/810dxfe/810dxme/811de/ 811dte/811dxe/811dfe/811dme/811dte/811dte/811dxfe/ 811dxme/812de/812dte/812dxe/812dfe/812dte/812dfe/ 812dme/812dte/812dxme/
NT-FPL701XBK	4000	4000	70C1HK0/70C2HK0/70C8HK0	●	Lexmark CS310dn/310n/410dtn/410n/410dn/510de/510dte
NT-FPL701XC	3000	3000	70C1HC0/70C2HC0/70C8HC0	●	
NT-FPL701XM	3000	3000	70C1HM0/70C2HM0/70C8HM0	●	
NT-FPL701XY	3000	3000	70C1HY0/70C2HY0/70C8HY0	●	
NT-FPL701BK	1000	1000	70C10K0/70C20K0/70C80K0	●	
NT-FPL701C	1000	1000	70C10C0/70C20C0/70C80C0	●	"Lexmark CS310dn/CS310n/CS310dn/CS410dtn/ CS410n/CS410dn/CS510dte/CS510de"
NT-FPL701M	1000	1000	70C10M0/70C20M0/70C80M0	●	Lexmark CS510dte/CS510de
NT-FPL701Y	1000	1000	70C10Y0/70C20Y0/70C80Y0	●	
NT-FPL701XXBK	8000	8000	70C0X10/70C2XK0/70C8XK0	●	
NT-FPL701XXC	4000	4000	70C0X10/70C2XC0/70C8XC0	●	
NT-FPL701XXM	4000	4000	70C0X10/70C2XM0/70C8XM0	●	
NT-FPL701XXY	4000	4000	70C0X10/70C2XY0/70C8XY0	●	Lexmkark CX310dn/CX310n/CX410de/CX410dte/ CX410e/CX510dhe/CX510dthe/CX510de
NT-FPL801BK	1000	1000	80C10K0/80C80K0/80C20K0	●	
NT-FPL801C	1000	1000	80C10C0/80C80C0/80C20C0	●	
NT-FPL801M	1000	1000	80C10M0/80C80M0/80C20M0	●	
NT-FPL801Y	1000	1000	80C10Y0/80C80Y0/80C20Y0	●	
NT-FPL801XXBK	4000	4000	80C1HK0/80C2HK0/80C8HK0	●	Lexmkark CX410de/CX410dte/CX410e/CX510dthe/ CX510dhe/CX510de
NT-FPL801XXC	3000	3000	80C1HC0/80C2HC0/80C8HC0	●	
NT-FPL801XXM	3000	3000	80C1HM0/80C2HM0/80C8HM0	●	
NT-FPL801XXY	3000	3000	80C1HY0/80C2HY0/80C8HY0	●	
NT-FPL801XXXBK	8000	8000	80C0X10/80C2XK0/80C8XK0	●	
NT-FPL801XXXC	4000	4000	80C0X10/80C2XC0/80C8XC0	●	Lexmark CX510dthe/CX510de/CX510dhe
NT-FPL801XXXM	4000	4000	80C0X10/80C2XM0/80C8XM0	●	
NT-FPL801XXXY	4000	4000	80C0X10/80C2XY0/80C8XY0	●	
NT-FPL801XBK	2500	2500	80C1SK0/80C2SK0/80C8SK0	●	
NT-FPL801XC	2000	2000	80C1SC0/80C2SC0/80C8SC0	●	
NT-FPL801XM	2000	2000	80C1SM0/80C2SM0/80C8SM0	●	Lexmark CX310n/310dn/410de/410dte/410e/ 510de/510dthe/510dhe
NT-FPL801XY	2000	2000	80C1SY0/80C2SY0/80C8SY0	●	
NT-PFL540BK	1000	1000	C540A1KG	●	
NT-PFL540C	1000	1000	C540A1CG	●	
NT-PFL540M	1000	1000	C540A1MG	●	
NT-PFL540Y	1000	1000	C540A1YG	●	Lexmark C543dn/C546dtn/X544n/C544dn/X544dn/ C544dtn/X546dtn/X548de/C540n/C544n/X544dw/ C544dw/X543dn/X548dte

Niestar Model NO.	PageYield		OEM Model	Color	For use in
	OEM	Niestar			
NT-PLE120C	2000	2000	12035SA/12015SA/12036SE/12016SE/12018SL/12017SL/12037SR/12017SR/0012036SE/0012016SE	●	Lexmark E120/E120N
NT-PLE230C	3000	3000	24035SA/24015SA/24036SE/24016SE/24018SL/34237HR/34217HR/24036SP/24016SP/24036S	●	Lexmark E230/E232/E232T/E234/E234N/E234TN/E240/E240N/E240T/E330/E332N/E332TN/E340/E342TN
NT-PLE250C	3500	3500	E250A21A/E250A11A/E250A21E/E250A11E/E250A11L/E250A11P/E250A21P	●	Lexmark E250D/E250DN/E350D/352DN
NT-PLE330C	6000	6000	34035HA/34015HA/34036HE/34016HE/34018HL/34237XR/34217XR	●	Lexmark E330/E340/E332N/E332TN/E342N
NT-PLE350XC	9000	9000	E352H21A/E352H11A/E352H21E/E352H11E/E352H11B/E352H21P/E352H12P/E352H21/E352H11P	●	Lexmark E350D/E352DN
NT-PLE450C	6000	6000	E450A21A/E450A11A/E450A21E/E450A11E/E450A11L/E450A11P/E450A21P	●	Lexmark E450DN
NT-PLE450XC	11000	11000		●	
NT-PLX340C	2500	2500	X340A21G/X340A11G/X340A12G	●	Lexmark X340/X340N/X342N
NT-PLX340XC	6000	6000	X340H21G/X340H11G/X340H12G	●	Lexmark X342N
NT-PL215	3200	3200	18S0090	●	Lexmark X215 MFP
NT-PL501B	/	/	50F1H00	●	Lexmark MS310d/310dn/410d/410dn/510dn/610dn/610de/610dtn/610dte
NT-PL501C	5000	5000	50F1H00/50F4H00/50F2H00/50F5H00/50F0HA0/50F3H00/50F5H0E/51F5H00/51F0HA0/51F5H0E	●	
NT-PL501X	10000	10000	50F1X00/50F4X00/50F2X00/50F5X00/50F0XA0/50F3X00	●	Lexmark MS410d/410dn/510dn/610dn/610de/610dtn/610dte
NT-PL501XC	10000	10000	50F1X00/50F4X00/50F2X00/50F5X00/50F0XA0/50F3X00	●	Lexmark MS410d/410dn/510dn/610dn/610de/610dtn/610dte
NT-PL501XXC	20000	20000	50F1U00/50F4U00/50F2U00/50F5U00/50F0UA0/50F3U00/50F5U0E	●	Lexmark MS510dn/610dn/610de/610dtn/610dte
NT-PFL5155	35000	35000	24B6015	●	Lexmark M5155/5163/5170/XM5163/5170
NT-PFL1145	16000	16000	24B6035	●	Lexmark M1145/XM1145

For use with: Lexmark

Niestar Model NO.	PageYield		OEM Model	Color	For use in
	OEM	Ninestar			
NT-PFL540XBK	2500	2500	C540H2KG	●	Lexmark C543dn/C546dtn/X544n/C544dn/X544dn/ C544dtn/X546dtn/X548de/C540n/C544n/X544dw/ C544dw/X543dn/X548dte
NT-PFL540XC	2000	2000	C540H2CG	●	
NT-PFL540XM	2000	2000	C540H2MG	●	
NT-PFL540XY	2000	2000	C540H2YG	●	
NT-PFL540XXBK	6000	6000	C544X2KG	●	Lexmark X544dn/C544dn/C544dtn/X544dw/C544n/ C544dw/X544n
NT-PFL540XXC	4000	4000	C544X2CG	●	
NT-PFL540XXM	4000	4000	C544X2MG	●	
NT-PFL540XXY	4000	4000	C544X2YG	●	
NT-PFL546XXBK	8000	8000	C546U2KG	●	Lexmark X548dte/C546dtn/X548de/X546dtn

For use with: Samsung

Niestar Model NO.	PageYield		OEM Model	Color	For use in
	OEM	Ninestar			
NT-PS3320C	3000	3000	MLT-D203S	●	Samsung ProXpress SL-M3320ND/3820D/DW/ 4020ND/M3370FD/M3870FW/M4070FR
NT-PS3320XC	5000	5000	MLT-D203L	●	Samsung Xpress SL-M3320/3820/4020/M3370/3870/4070
NT-PS3320XXC	10000	10000	MLT-D203E	●	Samsung Xpress SL-M3820/4020/M3870/4070
NT-PS3320XXXC	15000	15000	MLT-D203U	●	Samsung ProXpress SL-M4020/M4070
NT-PS3750XC	15000	15000	MLT-D305L	●	Samsung ML-3750ND
NT-PS404BK	1500	1500	404BK	●	Samsung Xpress C430/C430W/C480/C480W/ C480FN/C480FW
NT-PS404C	1000	1000	404C	●	
NT-PS404M	1000	1000	404M	●	
NT-PS404Y	1000	1000	404Y	●	
NT-PS403BK	1500	1500	CLT-K403S	●	Samsung SL-C435/SL-C436;Samsung SL-C485/SL-C486
NT-PS403C	1000	1000	CLT-C403S	●	
NT-PS403M	1000	1000	CLT-M403S	●	
NT-PS403Y	1000	1000	CLT-Y403S	●	
NT-PS405BK	1500	1500	MLT-K405S	●	Samsung SL-C422/SL-C423/SL-420W/SL-422W/ SL-C423W/SL-C472/SL-C473/SL-C470W/SL-C472W/ SL-C473W/SL-C470FW;SF-472FW/SF-C473FW
NT-PS405C	1000	1000	MLT-C405S	●	
NT-PS405M	1000	1000	MLT-M405S	●	
NT-PS405Y	1000	1000	MLT-Y405S	●	
NT-PS406BK	1500	1500	CLT-K406S	●	Samsung CLP-360/CLP-362/CLP-363/CLP-364/CLP-365/ CLP-365W/CLP-365EXP/CLP-367W/CLP-368;CLX-3300/ CLX-3302/CLX-3303/CLX-3303FW/CLX-3304/CLX-3305/ CLX-3305W/CLX-3305FN/CLX-3305FW/CLX-3305GOV/ CLX-3307W/CLX-3307FW/CLX-3307GOV
NT-PS406C	1000	1000	CLT-C406S	●	
NT-PS406M	1000	1000	CLT-M406S	●	
NT-PS406Y	1000	1000	CLT-Y406S	●	
NT-PS4072BK	1500	1500	CLT-K407S/CLT-K4072S	●	Samsung CLX-3180/CLX-3185/CLX-3185N/CLX-3185FN; CLP-320/CLP-320N/CLP-325
NT-PS4072C	1000	1000	CLT-C407S/CLT-C4072S	●	
NT-PS4072M	1000	1000	CLT-M407S/CLT-M4072S	●	
NT-PS4072Y	1000	1000	CLT-Y407S/CLT-Y4072S	●	
NT-PS409BK	1500	1500	CLT-K409S/CLT-K4092S	●	Samsung CLP-310/CLP-310N/CLP-315/CLP-315W; CLX-3170FN/CLX-3175/CLX-3175N/CLX-3175FN/ CLX-3175FW
NT-PS409C	1000	1000	CLT-C409S/CLT-C4092S	●	
NT-PS409M	1000	1000	CLT-M409S/CLT-M4092S	●	
NT-PS409Y	1000	1000	CLT-Y409S/CLT-Y4092S	●	
NT-PS300BK	2000	2000	CLP-K300A	●	Samsung CLP-300/CLP-300N/CLP-500/CLP-500N/ CLP-550/CLP-550N;CLX-2160/CLX-2160N/CLX-3160N/ CLX-3160FN
NT-PS300C	1000	1000	CLP-C300A	●	
NT-PS300M	1000	1000	CLP-M300A	●	
NT-PS300Y	1000	1000	CLP-Y300A	●	
NT-PS1610	2000	2000	ML-1610D2/SCX-4521D3/ML-2010D3/Dell310-6640/ SCX-4521D3ML-2010D3/Dell593-10094	●	Samsung ML-1610/ML-1615series/ML-2010/ML-2010R/ML-2010P/ ML-2010PR/ML-2015/ML-2510/ML-2570/ML-2571N;SCX-4521F/ SCX-4321;DellLaserPrinter1100/1110;Xerox Phaser3117/3124/ 3122/3125
NT-PS1610X	3000	3000		●	

For use with: Samsung

Niestar Model NO.	PageYield		OEM Model	Color	For use in
	OEM	Ninestar			
NT-PS1640C	1500	1500	MLT-D108S/MLT-D1082S	●	Samsung ML-1640/ML-2240/ML-2241/ML-1641/ ML-1645/ML-1640XSA
NT-PS1640	1500	1500		●	
NT-PS4650C	2500	2500	MLT-D117S	●	Samsung SCX-4650f/SCX-4650n/SCX-4655f/SCX-4650fn/ SCX-4650/SCX-4652F
NT-PS4725C	3000	3000	SCX-D4725A	●	Samsung SCX-4725F/SCX-4725FN
NT-PS1660C	1500	1500	MLT-D104S/MLT-D1042S	●	Samsung ML-1660K/ML-1665K/1661K/ML-1660/ML-1665/ ML-1865W/ML-1666/ML-1860/ML-1673/ML-1674/ ML-1673DCS/ML-1865K/ML-1864K/ML-1861K/ ML-1865DCS/ML-1865WK/ML-1865EXP;SCX-3200/ SCX-3210/SCX-3205/SCX-3217/SCX-3218/SCX-3205W/ SCX-3210K/SCX-3205K/SCX-3205HYP/SCX-3210DCS/ SCX-3210WK
NT-PS1710U	3000	3000	ML-1710D3/SCX-4216D3/SCX-4100D3/18S0090/ 109R00725/113R00667/18S0106	●	Samsung ML-1500/ML-1510/ML-1710/ML-1710P/ ML-1740/ML-1750;SCX-4016/SCX-4100/SCX-4116/ SCX-4216F;SF-560/SF-565P/SF-750/SF-755P; Lexmark X215MFP;Xerox Phaser3115/3120/3121/3130/ 3116;WorkCentrePE16
NT-PS4100	3000	3000	SCX-4100D3	●	Samsung SCX-4100
NT-PS4200C	3000	3000	SCX-D4200A	●	Samsung SCX-4200/SCX-4220
NT-PS4300C	2000	2000	MLT-D109S/MLT-D1092S	●	Samsung SCX-4300
NT-PS560RC	3000	3000	SF-D560RA	●	Samsung SF-560R/SF-565PR
NT-PS1910C	1500	1500	MLT-D105S/MLT-D1052S	●	Samsung ML-1910/ML-1910K/ML-1915/ML-1915K/ ML-1916K/ML-2525K/ML-2582K/ML-2525/ML-2525W/ ML-2580N/ML-1911/ML-2526/ML-2581N/ML-2540/ NL-2541/ML-2545/ML-2645/ML-2540R;SCX-4600/ SCX-4600K/SCX-4605K/SCX-4610K/SCX-4623K/ SCX-4623F/SCX-4623FN/SCX-4601/SCX-4623FW; SF-650/SF-650P
NT-PS1910XC	2500	2500	MLT-D105L/MLT-D1052L	●	
NT-PS1910X	2500	2500	MLT-D105L/MLT-D1052L	●	
NT-PS2020C	1000	1000	MLT-D111S	●	
NT-PS2020XC	1800	1800	MLT-D111L	●	Samsung Xpress SL-M2020/2022/2070
NT-PS2160	1500	1500	MLT-D101S	●	Samsung ML-2160/ML-2161/ML-2165W/ML-2162/ ML-2165/ML-2166/ML-2168/ML-2164/ML-2164W/ ML-2167/ML-2168W;SCX-3400/SCX-3405/SCX-3405W/ SCX-3405FW/SCX-3407/SCX-3400F/SCX-3405F/ SCX-3405FW;SF-760P
NT-PS2160C	1500	1500	MLT-D101S	●	
NT-PS2250X	5000	5000	ML-2250D5	●	Samsung ML-2250/ML-2251N/ML-2252W/ML-2251NP
NT-PS2250XC	5000	5000	ML-2250D5	●	Samsung ML-2250/ML-2251N/ML-2252W/ML-2251NP
NT-PS4720XC	5000	5000	SCX-4720D5/SCX-4720D3	●	Samsung SCX-4520/SCX-4720F/SCX-4720FN
NT-PS2625C	1200	1200	MLT-D116S	●	Samsung Xpress SL-M2625/2626/2825/2826/M2675/ 2676/2875/2876
NT-PS2625XC	3000	3000	MLT-D116L	●	
NT-PS2625X	3000	3000	MLT-D116L	●	Samsung SL- M3015DW;SL- M3065FW
NT-PS3015C	1200	1200	MLT-D118S	●	
NT-PS3015XC	4000	4000	MLT-D118L	●	Samsung ML-2850D/ML-2851ND/ML-2852/ML-2850ND
NT-PS2850C	2000	2000	ML-D2850A	●	
NT-PS2850	2000	2000	ML-D2850A	●	
NT-PS2850XC	5000	5000	ML-D2850B	●	Samsung ML-2855ND/ML-2855/ML-2855NDK/ML-2855G/ ML-2853D/ML-2853ND/ML-2853GOV;SCX-4828FN/ SCX4826FN/SCX-4825FN/SCX-4824FN/SCX-4824/ SCX-4825
NT-PS4828XC	5000	5000	MLT-D209L/MLT-D2092L	●	
NT-PS2620C	3000	3000	MLT-D115L	●	Samsung Xpress SL-M2620/2820/M2670/2870
NT-PS2950C	1500	1500	MLT-D103S	●	Samsung ML-2950ND/ML-2955ND/ML-2955DW/ ML-2951ND/ML-2951D/ML-2956ND/ML-2950D/ML-2955/ ML-2951GOV/ML-2950GOV;SCX-4728FD/SCX-4729FD/ SCX-4729FW/SCX-4729HD/XIL/SCX-4728HN/XIL/ SCX-4705/SCX-4726/SCX-4727/SCX-4728/SCX-4729/ SCX-4728GOV
NT-PS2950X	2500	2500	MLT-D103L	●	
NT-PS2950XC	2500	2500	MLT-D103L	●	
NT-PS2950X	2500	2500	MLT-D103L	●	
NT-PS3050C	4000	4000	ML-D3050A	●	Samsung ML-3050/ML-3051/ML-3051DN/ML-3051N
NT-PS3050XC	8000	8000	ML-D3050B	●	
NT-PS3050XXC	8000	10000	ML-D3050B	●	Samsung ML-3470D/ML-3471ND/ML-3472NDK/ML-3471
NT-PS3470C	4000	4000	ML-D3470A	●	
NT-PS3470XC	10000	10000	ML-D3470B	●	



For use with: Samsung

Niestar Model NO.	PageYield		OEM Model	Color	For use in
	OEM	Ninestar			
NT-PS5530C	4000	4000	SCX-D5530A	●	Samsung SCX-5530FN/SCX-5330N
NT-PS5530XC	8000	8000	SCX-D5530B	●	
NT-PS5635C	4000	4000	MLT-D208S/MLT-D2082S	●	Samsung ML-3475D/ML-3635FN/ML-5635FN/ML-3475ND/ML-3475GOV;SCX-5835FN/SCX-5635FNK
NT-PS5635XC	10000	10000	MLT-D208L/MLT-D2082L	●	
NT-PS5935C	10000	10000	MLT-D206L	●	Samsung SCX-5935fn/SCX-5935nx
NT-PS3310C	2000	2000	MLT-D205S	●	Samsung ML3312ND/ML3310/ML3712DW/ML3712ND/ML-3310ND/ML-3710/ML-3710D/ML-3710ND/ML-3710DW/ML-3310D;SCX-4835FR/SCX-5639FR/SCX-5739FW/SCX-4833/SCX-4833FD/SCX-4833FR/SCX-4835FD/SCX-5637/SCX-5637FR/SCX-5637FW/SCX-5639FR
NT-PS3310XC	5000	5000	MLT-D205L	●	
NT-PS3310XXC	10000	10000	MLT-D205E	●	
NT-PS205C	2000	2000	LT-D205S	●	
				●	

For use with: Xerox

Niestar Model NO.	PageYield		OEM Model	Color	For use in
	OEM	Ninestar			
NT-PX6110BK	2000	2000	106R01274/106R01203	●	Xerox Phaser 6110/6110MFP
NT-PX6110C	1000	1000	106R01271/106R01206	●	Xerox Phaser 6110/6110MFP
NT-PX6110M	1000	1000	106R01272/106R01205	●	Xerox Phaser 6110/6110MFP
NT-PX6110Y	1000	1000	106R01273/106R01204	●	Xerox Phaser 6110/6110MFP
NT-PX220U	3000	3000	013R00621	●	Xerox WorkCentre PE220
NT-PX3200C	3000	3000	113R00730/113R00735/CWAA0747	●	Xerox Phaser 3200MFP/3200MFP/B/3200MFP/N
NT-PX3119C	3000	3000	013R00625	●	Xerox 3119
NT-PX120XC	5000	5000	013R00601/013R00606	●	Xerox WorkCentre PE120/PE120i
NT-PX3150XC	5000	5000	109R00747	●	Xerox Phaser 3150/3150B
NT-PX3300C	4000	4000	106R01411	●	Xerox Phaser 3300MFP
NT-PX3300XC	8000	8000	106R01412	●	Xerox Phaser 3300MFP
NT-PX3428C	4000	4000	106R1245/CWAA0715	●	Xerox Phaser 3428
NT-PX3428XC	8000	8000	106R1246/CWAA0716	●	Xerox Phaser 3428
NT-PX3435C	4000	4000	106R01414/CWAA0762	●	Xerox Phaser 3435DN
NT-PX3435XC	10000	10000	106R01415/CWAA0763	●	Xerox Phaser 3435DN
NT-PX3140C	1500	1500	108R00908	●	Xerox Phaser 3140/3155/3160
NT-PX3140XC	2500	2500	108R00909	●	Xerox Phaser 3140/3155/3160
NT-PX3020C	1500	1500	106R02773	●	Xerox Phaser 3020;WorkCentre 3025
NT-PX3260C	1500	1500	106R02775/106R02782	●	Xerox Phaser 3052/3260;WorkCentre 3215NI/3225
NT-PX3260XC	3000	3000	106R02777/106R02778	●	Xerox Phaser 3052/3260;WorkCentre 3215NI/3225
NT-PX3210C	2000	2000	106R01485/CWAA0775	●	Xerox Workcentre 3210/3220
NT-PX3210XC	4100	4100	106R01486/106R01487/CWAA0776	●	Xerox Workcentre 3210/3220
NT-PX3250C	3500	3500	106R01373	●	Xerox Phaser 3250/3250D/3250DN
NT-PX3250XC	5000	5000	106R01374	●	Xerox Phaser 3250/3250D/3250DN
NT-PX3550C	5000	5000	106R01528/106R01529	●	Xerox WorkCentre 3550
NT-PX3550XC	11000	11000	106R01530/106R01531	●	Xerox WorkCentre 3550
NT-PX3635XC	10000	10000	108R00795	●	Xerox Phaser 3635MFP
NT-PX3320C	5000	5000	106R02305/106R01285/106R02304	●	Xerox Phaser 3320/DNI
NT-PX3320XC	11000	11000	106R02307/106R02306	●	Xerox Phaser 3320/DNI

For use with: Ricoh

Niestar Model NO.	PageYield		OEM Model	Color	For use in
	OEM	Ninestar			
NT-PR205C	3000	3000	TYPE2185(412660)/TYPE2285(412477)	●	Ricoh AC205;Aficio FX200/FX200L
NT-PRBP20C	5000	5000	402455	●	Ricoh BP20
NT-PR1210	2600	2600	SP1200A	●	Ricoh Aficio SP-1200/1200S/1200SF/1210/1210N

For use with: OKI

Niestar Model NO.	PageYield		OEM Model	Color	For use in
	OEM	Ninestar			
NT-PO3400BK	2500	2500	43459304/43459332/43459340/C33BTONEC/O3300BHY	●	OKI C3300n/C3400n/C3520/C3530n MFP/C3600n/MC360n MFP/MC630MFP/C3450
NT-PO3400C	2500	2000	43459303/43459331/43459339/C33CTONEC/O3300CHY	●	
NT-PO3400M	2500	2000	43459302/43459330/43459338/C33MTONEC/O3300MHY	●	
NT-PO3400Y	2500	2000	43459301/43459329/43459337/C33YTONEC/O3300YHY	●	
NT-PO3400UBK	2500	2500	43459304/43459332/43459340/C35BTONEHC/O3530B	●	OKI C3300/C3400/C3450/C3600/C3520MFP/C3530MFP (UniversalChip)
NT-PO3400UC	2000	2000	43459303/43459331/43459339/C35MTONEHC/O3530C	●	
NT-PO3400UM	2000	2000	43459302/43459330/43459338/C35CTONEHC/O3530M	●	
NT-PO3400UY	2000	2000	43459301/43459329/43459337/C35YTONEHC/O3530Y	●	

For use with: Konica

Niestar Model NO.	PageYield		OEM Model	Color	For use in
	OEM	Ninestar			
NT-PK4000C	20000	20000	A63W011F/A63W011H/A63W011K	●	Konica Minolta bizhub 4000P
NT-PK4700C	20000	20000	A63T011F/A63T011H/TNP-37/A63T011K	●	Konica Minolta bizhub 4700P
NT-PK3300C	10000	10000	TNP39	●	Konica Minolta bizhub 3300P
NT-PK3320C	10000	10000	TNP43	●	Konica Minolta bizhub 3320
NT-PK4020C	20000	20000	TNP42K	●	Konica Minolta bizhub 4020

